

Dismantling the Pump



Pumps which convey hazardous liquids must be decontaminated before dismantling the pump. The appropriate personal protection equipment should be used.

Tools required: Open ended spanner - across flats 15 mm, Torque wrench, Screwdriver - medium flat blade, Hide mallet, Allen key - 5 mm across flats.



1) Isolate the motor (1) from the power supply.

2) Disconnect the inlet and outlet connections.



Risk of contact with liquid being pumped.

3) Unscrew the wing nuts (8) by several turns and rotate the clamp lugs (7).

4) Remove the cover (18).


5) Unscrew the impeller locknut (22) with the spanner (right hand thread).

6) Slide the impeller (20) forward off the shaft (14) by maintaining an even pressure. Hitting the impeller can cause serious damage.

7) The mechanical seal (9) is now accessible. Clean the shaft and slide the seal forwards off the shaft.

8) The face of the seal is now exposed and can be inspected.

9) To remove the seal seat assembly (10,11), unscrew the flanged adaptor screws (4) and remove the flanged adaptor (5). The seal seat (11) and seat ring (10) can both be inspected.



Reassembling the Pump

1) Locate the seal seat assembly (10,11) in the flanged adaptor (5), fit the flanged adaptor onto the motor (1) and tighten the flanged adaptor screws (4). Take care during assembly that the seal seat (11) does not contact the shaft (14) and become chipped.

2) Fit the mechanical seal (9) (see page S2).

3) Slide the impeller (20) onto the pump stub shaft (14).

4) Screw on the impeller locknut (22) (right hand thread) and tighten to a torque of 30Nm.

5) Refit the cover (18).

6) Rotate the clamp lugs (7) into position and tighten the wing nuts (8), ensuring that the cover is correctly located.

7) Connect the inlet and outlet connections.

8) Before start-up, the pump should be flooded with liquid at the seal faces as dry running will cause overheating and may damage the mating surfaces.

Replacing the Seal - type 6D.

ATTENTION Mechanical seals are precision products. Installation should be carried out to the laid down procedure. Seals should be installed in a clean environment with particular care given to the lapped and polished seal faces.

Notes: - For information on the seal fitted in your pump, please refer to the data sheet.

Tools required: Diluted soft soap solution.

Removing the old seal:

Dismantle the pump and seal as described on page S1.

Fitting the new seal:

- 1) Ensure all components are clean. Any sharp edges on the shaft shoulder or keyway should be removed.
- 2) Fit the seat (2) into the seat ring (3) to form the seat assembly.
- 3) Press the seat assembly fully down into the recess in the flanged adaptor (1). Ensure that it is at right angles to the axis of the shaft and that the lapped sealing surface will face **towards** the mechanical seal assembly.
- 4) Fit the flanged adaptor (1) onto the motor and tighten the flanged adaptor screws. Take care during assembly that the seal seat does not contact the shaft and become chipped.
- 5) Ensure that the rubber bellows (4) are not cut or damaged during assembly.
- 6) Lubricate the inside sleeve of the bellows with a very slight smear of diluted soft soap solution. **Never use mineral oil, grease, vaseline**, etc, as it is **not** hygienic and may degrade the rubber.
- 7) Ensure that the bellows (4) is fully inserted into the seal face (5).
- 8) Slide the seal unit onto the shaft until it makes contact with the seat (2), making sure that the bellows (4) is fully compressed.
- 9) Reassemble the pump as described on page S1.
- 10) Before start-up, the pump should be flooded with liquid at the seal faces as dry running will cause overheating and may damage the mating surfaces.

