



Item	Description
1	Motor
2	Adaptor plate
3	Adaptor plate screws
4	Flanged adaptor bolts
5	Flanged adaptor
6	Housing plate screws
7	Clamp ring
8	Clamp ring handle and washer
9	Mechanical seal
10	Seal seat ring
11	Seal seat

Item	Description
12	Hoseguard cover (where fitted)
13	Shaft clamp
14	Stub shaft
15	Shaft guard
16	Housing plate
17	Cover joint ring
18	Cover
19	Impeller back plate (where fitted)
20	Impeller vane plate
21	Impeller key
22	Impeller lock nut