



Item	Description
1	Motor
2	Adaptor plate
3	Adaptor plate screws
4	Flanged adaptor bolts
5	Flanged adaptor
7	Clamp ring
8	Clamp ring handle and washer
9	Inboard mechanical seal
10	Inboard seal seat ring
11	Inboard seal seat
13	Shaft clamp
14	Stub shaft
15	Shaft guard

Item	Description
16	Housing plate
17	Cover joint ring
18	Cover
20	Impeller
21	Impeller key
22	Impeller lock nut
23	Flush connectors
24	Clamp plate
25	Outboard mechanical seal
26	Outboard seal seat
27	Outboard seal seat ring
28	Flush gasket
29	Clamp plate screws