



Item	Description
1	Motor
2	Adaptor plate
3	Adaptor plate screws
4	Flanged adaptor screws
5	Flanged adaptor
7	Clamp ring
8	Clamp ring handle and washer
9	Mechanical seal
10	Seal seat ring

Item	Description
11	Seal seat
13	Shaft clamp
14	Stub shaft
16	Housing plate
17	Cover joint ring
18	Cover
20	Impeller
21	Impeller key
22	Impeller lock nut