



Item	Description
1	Motor
2	Adaptor plate
3	Adaptor plate screws
4	Flanged adaptor bolts
5	Flanged adaptor
7	Clamp ring
8	Clamp ring handle and washer
9	Mechanical seal unit
10	Seal seat ring
11	Seal seat

Item	Description
13	Shaft clamp
14	Stub shaft
16	Housing plate
17	Cover joint ring
18	Cover
19	Impeller back plate (where fitted)
20	Impeller vane plate
21	Impeller key
22	Impeller lock nut
40	Impeller joint ring